

Magnetic Marker Board



With a magnetic porcelain enameled steel face, our wall panels with dry erase surfaces are high-performing and resistant to scratches, stains and fading, and can be written on with semi-permanent, water-soluble or permanent marker, chalk, pen or crayon without damaging the surface.

PSI Marker Board panels are made for intensive everyday use. They are designed to work together with other PSI surfaced panels such as Tack Boards and HPL or Wood Veneer panels.

Marker Board Benefits:

- The porcelain steel magnetic marker board surface can be written on with dry-erase, semi-permanent, water soluble or permanent markers without damaging the writing surface.
- Dry erase ink can be wiped off with a dry cloth or standard eraser.
- Semi-permanent and permanent marker pen inks can be removed with a solvent based cleaner.
- The smooth glass like porcelain surface eliminates ghosting in improves erasability. It provides superior color contrast vs. glass marker board surfaces.
- The surface is durable and is highly resistant to scratching.



REVIT MODEL INSTRUCTIONS

Thank you for downloading the Panel Specialists Revit products.

To transfer the Curtain Wall types and their materials:


Make sure your project and the Panel Specialists project are open in the same session of Revit. In your project, go to Manage tab and click Transfer Project Standards. When the "Select Items To Copy" window opens, select the Panel Specialists Showcase project. Click "Check None" and find the "Curtain Wall Types" in the menu to check. Click OK. On the "Duplicate Types" window select the "New Only" Option. All curtain wall types and their materials are now in your project ready to be used.

To transfer an individual Curtain Wall/Curtain Panel/Curtain Wall Mullions with its materials:

If only one product is needed, you can copy and paste the desired curtain wall/curtain panel/curtain wall mullions (under Project Browser > Walls> Curtain Wall, or Project Browser > Curtain Panels or Project, or Project Browser > Curtain Wall Mullions or Project) by right-clicking it and selecting "Copy to Clipboard". Go to your project and paste it (Ctrl-V)

To build the required curtain wall:

Please choose the type of curtain wall you would like to build in your project from the listed under Project Browser > Walls> Curtain Wall. Build the selected system according to the required size.



System 410

Molding Options:


Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 410
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Raw & Square panel edges without edge banding

Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.



System 412

Molding Options:

Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 412 (with optional flat or concave insert)
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Raw & Square panel edges without edge banding

Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.