

Tack Board



PSI Tack Board panels are made with Forbo Bulletin board bonded to a wood composite core. The Tack Board panels are designed to be an integral part of a wall surfaced in a PSI Wall Panel System.

Our tack boards are durable and long-lasting in high-usage situations. PSI tack boards utilize Forbo's bulletin board surfaces, which are the industry standard in self-healing, tackable, washable, decorative wall surfaces.

Tack Board Benefits:

- The Bulletin Board surface is produced from natural and renewable raw materials. A combination of cork, linseed oil and rosin.
- The board material retains its grip and does not crumble like traditional soft boards as the pinholes close after extraction of the pins.
- The surface does not attract dust and has bacteriostatic properties, making it an ideal solution in educational settings and a hygienic choice in healthcare environments.
- Tackboard Panels are available up to 10' length, with nominal sizes below 10' & 8' long.
- Panel edges are covered with PSI #410 divider moldings and edge trims. The panels are flat and bridge gaps in uneven or undulating walls.
- The Forbo Bulletin Board is available in 15 standard finishes from muted tones to vibrant primary colors.



REVIT MODEL INSTRUCTIONS

Thank you for downloading the Panel Specialists Revit products.

To transfer the Curtain Wall types and their materials:

Make sure your project and the Panel Specialists project are open in the same session of Revit. In your project, go to Manage tab and click Transfer Project Standards. When the "Select Items To Copy" window opens, select the Panel Specialists Showcase project. Click "Check None" and find the "Curtain Wall Types" in the menu to check. Click OK. On the "Duplicate Types" window select the "New Only" Option.

All curtain wall types and their materials are now in your project ready to be used.

To transfer an individual Curtain Wall/Curtain Panel/Curtain Wall Mullions with its materials:

If only one product is needed, you can copy and paste the desired curtain wall/curtain panel/curtain wall mullions (under Project Browser > Walls> Curtain Wall, or Project Browser > Curtain Panels or Project, or Project Browser > Curtain Wall Mullions or Project) by right-clicking it and selecting "Copy to Clipboard". Go to your project and paste it (Ctrl-V)


To build the required curtain wall:

Please choose the type of curtain wall you would like to build in your project from the listed under Project Browser > Walls> Curtain Wall. Build the selected system according to the required size.

To transfer Panel Specialists Material Library to your Revit file:

Save the .adsklib file in your desired location (computer or network). In your Revit project ribbon menu choose Manage>Materials>Open Existing library. Choose the downloaded library from its location. Load materials of your preference into the project either by dragging them to material box or using the loading arrow. Click OK.

Please be sure to download the "Panel Specialists_Texture Images.zip" file, extract it and copy texture files to the following location: C:\Program Files (x86)\Common Files\Autodesk Shared\Materials\Textures\Panel Specialists_Texture Images.



System 410

Molding Options:


Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 410 (with optional flat or concave insert)
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Raw & Square panel edges without edge banding

Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert) Optional Outside Corners: 603-90 -OR- 603-135

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.



System 412

Molding Options:

Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 412
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Raw & Square panel edges without edge banding

Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert) Optional Outside Corners: 603-90 -OR- 603-135

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.