


Wood Veneer



Timeless and beautiful, wood veneer panels bring an added touch of warmth, elegance and style to any space. And when you choose PSI, you know you are making a choice that reflects quality, craftsmanship, and design.

Maximize the aesthetic quality and vision of your next project when you specify wood veneers from the leader in commercial wall panel systems.

Rich in Beauty + Design:

- Clear-coated and custom stains in a gloss or satin finish.
- 29 natural and timeless veneers are in our standard offering. Most other veneers are available on request.
- Environmentally friendly UV coating adds durability - protecting your investment while maintaining the panel's beauty.
- Finished wood edge banding on all panels.
- Flexibility to mix and match with other PSI panels so you can utilize multiple products in a single space.
- Carefully selected veneers in both A and AA architectural grade distinctions.
- Panel to panel joints, corners and edge trims are engineered into the system design for ease of specification, installation and lower cost compared to mill work.



REVIT MODEL INSTRUCTIONS

Thank you for downloading the Panel Specialists Revit products.

To transfer the Curtain Wall types and their materials:

Make sure your project and the Panel Specialists project are open in the same session of Revit. In your project, go to Manage tab and click Transfer Project Standards. When the "Select Items To Copy" window opens, select the Panel Specialists Showcase project. Click "Check None" and find the "Curtain Wall Types" in the menu to check. Click OK. On the "Duplicate Types" window select the "New Only" Option.

All curtain wall types and their materials are now in your project ready to be used.

To transfer an individual Curtain Wall/Curtain Panel/Curtain Wall Mullions with its materials:

If only one product is needed, you can copy and paste the desired curtain wall/curtain panel/curtain wall mullions (under Project Browser > Walls> Curtain Wall, or Project Browser > Curtain Panels or Project, or Project Browser > Curtain Wall Mullions or Project) by right-clicking it and selecting "Copy to Clipboard". Go to your project and paste it (Ctrl-V)

To build the required curtain wall:


Please choose the type of curtain wall you would like to build in your project from the listed under Project Browser > Walls> Curtain Wall. Build the selected system according to the required size.

To transfer Panel Specialists Material Library to your Revit file:

Save the .adsklib file in your desired location (computer or network). In your Revit project ribbon menu choose Manage>Materials>Open Existing library. Choose the downloaded library from its location. Load materials of your preference into the project either by dragging them to material box or using the loading arrow. Click OK.

Please be sure to download the "Panel Specialists_Texture Images.zip" file, extract it and copy texture files to the following location: C:\Program Files (x86)\Common Files\Autodesk Shared\Materials\Textures\Panel Specialists_Texture Images.

Molding Options:



Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 302 -OR- 302A
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Machined/Kerfed panel edges with matching veneer edge band


Optional Perimeter Trims: 305, 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 314 -OR-312 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

System 310

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.

Molding Options:



Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 412 (with optional flat or concave insert)
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Square panel edges with matching veneer edge band

Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

System 412

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.

Molding Options:



Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 302 -OR- 302A
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Machined/Kerfed panel edges with matching veneer edge band


Optional Perimeter Trims: 305, 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 314 -OR-312 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

System 310EB

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.

Molding Options:



Basis of design:
Perimeter Trims: 604/604A
Profile Divider Reveals: 631, 1/4" wide
Outside corners: 603-90 -OR- 603-135

HPL Panel Style: Machined/Kerfed panel edges with matching veneer edge band


Optional Perimeter Trims: 305, 304 Angled Top Trim, 404WC, 304/304A
Optional Profile Divider Reveals: 632
Optional Outside Corners: 103-90 -OR- 103-135

System 631

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.

Molding Options:



Basis of design:
Perimeter Trims: 304/304A
Profile Divider Reveals: 410
Outside corners: 103-90 -OR- 103-135

HPL Panel Style: Square panel edges with matching veneer edge band


Optional Perimeter Trims: 304 Angled Top Trim, 404WC, 604/604A
Optional Profile Divider Reveals: 410-A -OR- 412 (optional concave or flat insert)
Optional Outside Corners: 603-90 -OR- 603-135

System 410

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.

Molding Options:



Basis of design:
Perimeter Trims: 604/604A
Profile Divider Reveals: 632
Outside corners: 603-90 -OR- 603-135

HPL Panel Style: Machined/Kerfed panel edges with matching veneer edge band

Optional Perimeter Trims: 305, 304 Angled Top Trim, 404WC, 304/304A
Optional Profile Divider Reveals: 631
Optional Outside Corners: 103-90 -OR- 103-135

System 632

If combined with FORBO Tack Board or Porcelain over Steel Markerboards, use only 410/410-A/412 dividers.

Tack Board and Porcelain over Steel Markerboard Panels MUST be captured on all sides.